




**Translation of the Original
Operating Manual**

GM 5000EAC

Version 07/2014

**Electrostatic AirCoat Spray Gun for
Manual Operation and for Flat or
Round Jet Nozzles**



B_03154



Contents

1	ABOUT THIS OPERATING MANUAL	6
1.1	Preface	6
1.2	Warnings, Notices, and Symbols in this Operating Manual	6
1.3	Languages	7
1.4	Abbreviations	7
2	CORRECT USE	8
2.1	Device Type	8
2.2	Correct Use	8
2.3	Use in an Explosion Hazard Area	8
2.4	Safety Parameters	8
2.5	Processible Products	9
2.6	Reasonably Foreseeable Misuse	10
2.7	Residual Risks	10
3	IDENTIFICATION	11
3.1	Explosion Protection Identification FM	11
3.2	Information for safe and correct operation	11
3.3	Permissible Device Combinations	12
4	GENERAL SAFETY INSTRUCTIONS	13
4.1	Safety Instructions for the Operator	13
4.1.1	Electrical Equipment	13
4.1.2	Staff Qualifications	13
4.1.3	Safe Work Environment	13
4.2	Safety Instructions for Staff	14
4.2.1	Safe Handling of WAGNER Spray Devices	14
4.2.2	Grounding the Device	15
4.2.3	Material Hoses	15
4.2.4	Cleaning	16
4.2.5	Handling Hazardous Liquids, Varnishes, and Paints	17
4.2.6	Touching Hot Surfaces	17
4.3	Correct Use	17
4.4	Safety Information on Discharges	18
4.5	Use in an Explosion Hazard Area	18
4.6	Notes to German Regulations and Guidelines	18
5	DESCRIPTION	19
5.1	Functional Description	19
5.1.1	Design of the Spray Gun (Basic Version)	19
5.1.2	Functioning of the Spray Gun	20
5.2	Scope of Delivery	22
5.3	Technical Data	23
5.4	Spray Process	24
5.4.1	AirCoat Round Jet Spray Process	24
5.4.2	AirCoat Flat Jet Spray Process	24
5.4.3	Electrostatic Effect	25

Table of Contents

6	COMMISSIONING AND OPERATION	26
6.1	Training Assembly/Commissioning Staff	26
6.2	Storage Conditions	26
6.3	Installation Conditions	26
6.4	Installation and Connection	27
6.4.1	Typical Electrostatic Spraying System	27
6.4.2	Ventilation of the Spray Booth	28
6.4.3	Air Supply	29
6.4.4	Material Supply	29
6.4.5	Grounding	30
6.5	Preparation of Lacquer	33
6.5.1	Viscosity Conversion Table	33
6.6	Commissioning	34
6.6.1	General Rules for Manipulation of the Spray Gun	34
6.6.2	Preparation for Starting Up	34
7	OPERATION	37
7.1	Training the Operating Staff	37
7.2	Safety Instructions	37
7.3	Work	38
7.3.1	Filling with Working Product	38
7.3.2	Start-up for Spraying AirCoat	39
7.3.3	Flushing Out Clogged Round Jet Nozzles	40
7.3.4	Replacing Round Jet Nozzle's Nozzle Insert	40
7.3.5	Changing from AirCoat Round Jet to AirCoat Flat Jet	41
7.3.6	Replacing the AirCoat Flat Jet Nozzles	42
7.3.7	Cleaning of the Nozzle Parts	42
7.3.8	Eliminate Nozzle Clogging	42
7.3.9	Changing the Valve Housing	44
8	CLEANING AND MAINTENANCE	45
8.1	Cleaning	45
8.1.1	Cleaning Staff	45
8.1.2	Safety Instructions	45
8.1.3	Cleaning and Decommissioning	46
8.2	Maintenance	48
8.2.1	Maintenance Staff	48
8.2.2	Safety Instructions	48
8.3	Disassembly of the Spray Gun	49
8.3.1	Tools	49
8.3.2	Disassembly of the Spray Gun	50
8.4	Cleaning the Parts after Disassembly	53
8.5	Assembly of the Spray Gun	54
8.6	Function Test after Assembly of the Gun	59
8.6.1	Test of the High-Voltage	59
8.6.2	Air Test	60
8.6.3	Product Pressure Test	60
8.6.4	Test of Spray Pattern	61
8.7	High-Pressure Hoses	62

Table of Contents

9	INSPECTIONS	63
9.1	Periodical Inspections	63
10	TROUBLESHOOTING AND RECTIFICATION	64
11	PRODUCT DISPOSAL	65
12	ACCESSORIES	66
12.1	Round Jet Nozzles	66
12.1.1	ACR 5000 Round Jet Nozzle Cap	66
12.1.2	AirCoat Round Jet Nozzle Inserts	66
12.2	Flat Jet Nozzles	66
12.2.1	ACF 5000 Air Caps (Flat Jet)	66
12.2.2	ACF5000 AirCoat Flat Jet Nozzles	67
12.3	Filter	69
12.4	Reduction Fittings for High-Pressure Hoses	69
12.5	Hoses and Electric Cables	70
12.5.1	Standard Hose Sets and Components	70
12.5.2	Hose Sets for Low-resistance Products	72
12.5.3	Gun Cables and Gun Cable Extensions	74
12.6	Miscellaneous	74
13	SPARE PARTS	77
13.1	How Can Spare Parts Be Ordered?	77
13.2	GM 5000EAC Spare Parts List	78
13.2.1	GM 5000EAC - Adapter Spare Parts List	80
13.2.2	GM 5000EAC - Handle Spare Parts List	82
13.3	Accessories Spare Parts Lists	84
13.3.1	Flat Jet Nozzles Spare Parts List	84
13.3.2	ACR 5000 Round Jet Nozzle Cap Spare Parts List	85
14	WARRANTY	86
14.1	Important Notes Regarding Product Liability	86
14.2	Warranty Claim	86

1 ABOUT THIS OPERATING MANUAL

1.1 PREFACE

The operating manual contains information about safely operating, maintaining, cleaning and repairing the device.

The operating manual is part of the device and must be available to operating and service staff.

Operating and service staff should be instructed according to the safety instructions.

The device may only be operated in compliance with this operating manual.

This equipment can be dangerous if it is not operated according to the instructions in this operating manual.

Electrostatic spray guns may only be operated by trained personnel.

1.2 WARNINGS, NOTICES, AND SYMBOLS IN THIS OPERATING MANUAL

Warning instructions in this operating manual highlight particular dangers to users and to the device and state measures for avoiding the hazard. These warning instructions fall into the following categories:

Danger - immediate risk of danger.
Non-observance will result in death or serious injury.

	 DANGER
	<p>This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.</p> <p>→ The following are measures which can be taken to prevent the hazard and its consequences.</p>

Warning - possible imminent danger.
Non-observance may result in death or serious injury.

	 WARNING
	<p>This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.</p> <p>→ The following are measures which can be taken to prevent the hazard and its consequences.</p>

Caution - a possibly hazardous situation.
Non-observance may result in minor injury.

	 CAUTION
	<p>This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.</p> <p>→ The following are measures which can be taken to prevent the hazard and its consequences.</p>

Notice - a possibly hazardous situation.
Non-observance may result in material damage.

NOTICE
<p>This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.</p> <p>→ The following are measures which can be taken to prevent the hazard and its consequences.</p>

Note - provides information about particular characteristics and how to proceed.

1.3 LANGUAGES

The operating manual is available in the following languages:

German

English

2344500

1.4 ABBREVIATIONS

Order No.	Order number
ET	Spare part
K	Marking in the spare parts lists
Low R	Low-resistance
Pos	Position
Stk	Number of pieces
SW	Width across flats

2 CORRECT USE

2.1 DEVICE TYPE

Electrostatic manual spray gun for manual coating of grounded work pieces

2.2 CORRECT USE

The GM 5000EAC electrostatic hand spray gun is suitable for spraying liquid products, particularly coating products, using the AirCoat method. Coating products containing solvents of explosion class II A may be used.

2.3 USE IN AN EXPLOSION HAZARD AREA

The GM 5000EAC electrostatic manual spray gun is suitable for coating electrically conductive objects with liquid coating products and can be used in potentially explosive areas. (See Chapter 3 "Identification".)

2.4 SAFETY PARAMETERS

The GM 5000EAC electrostatic manual spray gun is only suitable for spraying liquid products, particularly coating products.

J. Wagner AG forbids any other use!

The electrostatic manual spray gun may only be operated under the following conditions:

- the operating staff have previously been trained on the basis of this operating manual,
- the safety regulations listed in this operating manual are observed,
- the operating, maintenance and repair information in this operating manual is observed,
- and the statutory requirements and accident prevention regulations standards in the country of use are observed.

The electrostatic manual spray gun may only be operated if all parameters are set and all measurements/safety checks are carried out correctly.

2.5 PROCESSIBLE PRODUCTS

- With the GM 5000EAC gun, paints can be applied which contain solvents of explosion class II A.
- The spray gun basic version is suitable for processing sprayed substances with an electrical resistance of $> 150 \text{ k}\Omega$ (according to the WAGNER scale).
Equipped with a special product hose for low-resistance sprayed substances (available as an accessory) you can also successfully process sprayed substances with an electrical resistance $> 50 \text{ k}\Omega$ (according to the WAGNER scale).
- The transfer efficiency is always dependant on the composition of the product being used, e.g. pigmentation or resin.

Conversion of Paint Resistance

There are paint resistance measuring devices available on the market that do not directly measure the specific paint resistance.

Multiplying the result of the measurement with the device-specific cell constant (K), we obtain the specific resistance value of the product.

Example:

With Wagner's paint resistance measuring device the cell constant is $K = 123$.

Measured value according to the WAGNER scale $R = 500 \text{ k}\Omega$

Specific resistance (RS) $RS = R \times K = 500 \text{ k}\Omega \times 123 = 61.5 \text{ M}\Omega.\text{cm}$

Notice

Using sprayed substances with too low an electrical resistance, the application of electrostatics does not show any effect, i.e. there is no "paint wrap around" on the object to be sprayed.

The suitability of the sprayed product with regard to the charging ability can be read from the indicators showing the actual values for the high-voltage (kV) and for the spray current (μA) the actual values are shown either on the VM 5000 control unit or on the spray gun.

high kV value, low μA value	= ok.
low kV value, high μA value	= excessive conductivity of the paint
	-> no wrap-around

In the event of application problems, please contact your local WAGNER office and the paint manufacturer.

2.6 REASONABLY FORESEEABLE MISUSE

- Processing inadmissible coating products
- Use of defective spare parts
- Use for foodstuffs
- Use in the pharmaceutical sector

2.7 RESIDUAL RISKS

Residual risks are risks which cannot be excluded even in the event of correct use. If necessary, warning and prohibition signs at the relevant points of risk indicate residual risks.

Residual risk	Source	Consequences	Specific measures	Lifecycle phase
Skin contact with solvent-based paints and cleaning agents	Handling of solvent-based paints and cleaning agents	Skin irritations, allergies	Wear protective clothing, observe safety data sheets	Operation, maintenance, disassembly
Solvent-based paint in air outside the defined working area	Painting outside the defined working area	Inhalation of substances hazardous to health	Observe work and operation instructions	Operation, maintenance

3 IDENTIFICATION

3.1 EXPLOSION PROTECTION IDENTIFICATION FM



For Electrostatic Finishing Applications
using Class I, Group D, Spray Material

In accordance with 2316160

This device has been manufactured and tested by FM, according to the FM (Factory Mutual) standard "Class Number 7260" (Approval Standard for Electrostatic Finishing Equipment). All tested combinations of devices including accessories are given in the FM Control Document with part number 2316160.

3.2 INFORMATION FOR SAFE AND CORRECT OPERATION

Maximum surface temperature

- Maximum surface temperature: 85 °C; 185 °F
- Maximum permissible product temperature: 50 °C; 122 °F
- Permissible ambient temperature: 0 to +40 °C; +32 to +104 °F

Safety instructions

Safe handling of WAGNER spray devices

Mechanical sparks can form if the device comes into contact with metal.

In an explosive atmosphere:

- Do not knock or push the unit against steel or rusty iron.
- Do not drop the spray gun.
- Only use tools that are made of a permitted material.

Ignition temperature of the coating product

- Ensure that the ignition temperature of the coating material is above the maximum surface temperature.



Surface spraying, electrostatics

→ Never spray device parts using electrostatic equipment (electrostatic spray gun!).



Medium supporting atomizing

→ To atomize the product, use only weakly oxidizing gases, e.g. air.

Cleaning

If there are deposits on the surfaces, the device may form electrostatic charges. Flames or sparks can form during discharge.

→ Remove deposits from the surfaces to maintain conductivity.

→ Only use a damp cloth to clean the device.



3.3 PERMISSIBLE DEVICE COMBINATIONS

	WARNING
	<p>Incorrect use! Risk of injury and equipment damage.</p> <p>→ Connect the GM 5000EAC manual spray gun only to original Wagner control units.</p>

The GM 5000EAC manual spray gun may only be connected to the control units listed below:

<ul style="list-style-type: none"> ● VM 500 control unit
<ul style="list-style-type: none"> ● VM 5000 control unit

4 GENERAL SAFETY INSTRUCTIONS

4.1 SAFETY INSTRUCTIONS FOR THE OPERATOR

- Keep this operating manual at hand near the unit at all times.
- Always follow local regulations concerning occupational safety and accident prevention.



4.1.1 ELECTRICAL EQUIPMENT

Electrical devices and equipment

- To be provided in accordance with the local safety requirements with regard to the operating mode and ambient influences.
- May only be maintained by skilled electricians or under their supervision.
- Must be operated in accordance with the safety regulations and electrotechnical regulations.
- Must be repaired immediately in the event of problems.
- Must be decommissioned if they pose a hazard.
- Must be de-energized before work is commenced on active parts. Inform staff about planned work. Observe electrical safety regulations.




4.1.2 STAFF QUALIFICATIONS

- Ensure that the device is operated and repaired only by trained persons.

4.1.3 SAFE WORK ENVIRONMENT

- Ensure that the floor in the working area is static dissipative in accordance with EN 61340-4-1 (resistance must not exceed 100 Mohm).
- Ensure that all persons within the working area wear static dissipative shoes. Footwear must comply with EN 20344. The measured insulation resistance must not exceed 100 Mohm.
- Ensure that during spraying, persons wear static dissipative gloves. The grounding takes place via the spray gun handle.
- If protective clothing is worn, including gloves, it has to comply with EN 1149-5. The measured insulation resistance must not exceed 100 Mohm.
- Paint mist extraction systems must be fitted on site according to local regulations.
- Ensure that the following components of a safe working environment are available:
 - Product/air hoses adapted to the working pressure.
 - Personal safety equipment (breathing and skin protection).
- Ensure that there are no ignition sources such as naked flames, sparks, glowing wires, or hot surfaces in the vicinity. Do not smoke.



4.2 SAFETY INSTRUCTIONS FOR STAFF

- Always follow the information in this manual, particularly the general safety instructions and the warning instructions.
- Always follow local regulations concerning occupational safety and accident prevention.



4.2.1 SAFE HANDLING OF WAGNER SPRAY DEVICES

The spray jet is under pressure and can cause dangerous injuries.

Avoid injection of paint or cleaning agents:

- Never point the spray gun at people.
- Never reach into the spray jet.
- Before all work on the device, in the event of work interruptions and functional faults:
 - Switch off the energy/compressed air supply.
 - Relieve the pressure from the spray gun and device.
 - Secure the spray gun against actuation.
 - In the event of functional faults: remedy the fault as described in the "Troubleshooting" chapter.
- The liquid ejection devices are to be checked for safe working conditions by an expert (e.g. Wagner Service Technician) as often as necessary or at least every 12 months, in accordance with the guidelines for liquid ejection devices (ZH 1/406 and BGR 500 Part 2 Chapter 2.36).
 - For shut down devices, the examination can be suspended until the next commissioning.
- Carry out the work steps as described in the "Pressure Relief/Work Interruptions" chapter:
 - if pressure relief is required.
 - if the spraying work is interrupted or stopped.
 - before the device is cleaned on the outside, checked, or serviced.
 - before the spray nozzle is installed or cleaned.



In the event of skin injuries caused by paint or cleaning agents:

- Note down the paint or cleaning agent that you have been using.
- Consult a doctor immediately.

Avoid danger of injury through recoil forces:

- Ensure that you have firm footing when operating the spray gun.
- Only hold the spray gun briefly in a position.

4.2.2 GROUNDING THE DEVICE

In order to avoid electrostatic charging of the device, the device must be grounded. Friction, flowing liquids, and air or electrostatic coating processes create charges. Flames or sparks can form during discharge.

- Ensure that the device is grounded at all times.
- Ground the work pieces to be coated.
- Ensure that all persons inside the working area are grounded, e.g. that they are wearing static dissipative shoes.
- Wear dissipative gloves when spraying. The grounding takes place via the spray gun handle.
- Grounding of the coating product supply (coating product tank, pump, etc.) is mandatory.



4.2.3 MATERIAL HOSES

- Ensure that the hose material is chemically resistant to the sprayed products.
- Ensure that the product hose is suitable for the pressure generated in the device.
- Ensure that the following information can be seen on the high-pressure hose:
 - Manufacturer
 - Permissible operating overpressure
 - Date of manufacture
- Make sure that the hoses are laid only in suitable places. In no case, should hoses be laid in the following places:
 - in high-traffic areas,
 - on sharp edges,
 - on moving parts, or
 - on hot surfaces
- Make sure that the hoses are never used to pull or move the equipment.
- The electrical resistance of the complete high-pressure hose must be less than 1 Mohm.



4.2.4 CLEANING

- De-energize the device electrically.
- Disconnect the pneumatic supply line.
- Relieve the pressure from the device.
- Ensure that the flash point of the cleaning agent is at least 15 K above the ambient temperature or that cleaning is undertaken at a cleaning station with technical ventilation.
- To clean, use cloths and brushes moistened with solvent. Abrasive agents or objects must not be used. Ensure that the spray gun is not damaged in any way while cleaning.
- Parts of the spray gun must not be sprayed with or immersed into cleaning agent.
- Preferably, non-combustible cleaning agents should be used.
- The choice of the appropriate cleaning agent depends on which parts of the spray gun have to be cleaned and which product has to be removed. When cleaning the spray gun only use **non-polar cleaning agents** to prevent conductive residues on the surface of the spray gun. Should it however, be necessary to use a polar cleaning agent, all residues of this cleaning agent have to be removed by using a non-conductive and non-polar cleaning agent, once the cleaning is finished.
- Ensure that no electrical component is cleaned with nor even immersed into solvent.



An explosive gas/air mixture forms in closed tanks.

- When cleaning devices with solvents, never spray into a closed tank.
- Only use electrically conductive tanks for cleaning liquids.
- The tanks must be grounded.



4.2.5 HANDLING HAZARDOUS LIQUIDS, VARNISHES, AND PAINTS

- When preparing or working with paint and when cleaning the device, follow the working instructions of the manufacturer of the paints, solvents, and cleaning agents being used.
- Take the specified protective measures. In particular, wear safety goggles, protective clothing and gloves, as well as skin protection cream if necessary.
- Use a mask or a breathing apparatus if necessary.
- For sufficient health and environmental safety: operate the device in a spray booth or on a spraying wall with the ventilation (extraction) switched on.
- Wear suitable protective clothing when working with hot products.



4.2.6 TOUCHING HOT SURFACES

- Only touch hot surfaces if you are wearing protective gloves.
- When operating the device with a coating product with a temperature of $> 43\text{ }^{\circ}\text{C}$; $109.4\text{ }^{\circ}\text{F}$:
 - Identify the device with a warning label "Warning - hot surface".



Order No.

9998910 Instruction label

9998911 Protection sticker

Note: Order the two stickers together.

4.3 CORRECT USE

WAGNER accepts no liability for any damage arising from incorrect use.

- Use the device only to work with the products recommended by WAGNER.
- Only operate the device as a whole.
- Do not deactivate safety fixtures.
- Use only WAGNER original spare parts and accessories.



4.4 SAFETY INFORMATION ON DISCHARGES

The plastic parts of the spray gun are charged electrostatically by the high-voltage field of the spray gun. In case of contact with plastic parts harmless discharges (brush discharges) may occur. They are completely non-hazardous for human health.

When keeping a distance of 4 to 10 mm; 0.15 to 0.4 inch between spray gun and object to be sprayed, the corona discharge at the end of the electrode is visible during darkness.

4.5 USE IN AN EXPLOSION HAZARD AREA

In explosion hazard areas only use approved explosion-proof electrical devices.

4.6 NOTES TO GERMAN REGULATIONS AND GUIDELINES

- a) BGV A3 Electrical devices and equipment
- b) BGR 500 Part 2, Chapter 2.36 Working with Liquid Ejection Devices
- c) BGR 500 Part 2, Chapter 2.29 Working with Coating Products
- d) BGR 104 Explosion protection rules
- e) TRBS 2153 Avoiding ignition risks
- f) BGR 180 Equipment for cleaning work pieces with solvents
- g) ZH 1/406 Guidelines for liquid ejection devices
- h) BGI 740 Painting rooms and equipment
- i) BGI 764 Electrostatic coating
- j) Betr.Sich.V. Plant Safety Ordinance

Note: All titles can be ordered from Heymanns Publishing House in Cologne, or they can be found on the Internet.


5 DESCRIPTION

5.1 FUNCTIONAL DESCRIPTION

5.1.1 DESIGN OF THE SPRAY GUN (BASIC VERSION)


Note:

The nozzle parts (pos 6; 7; 13 and 14) do not belong to the basic equipment of the spray gun. The different versions can be found in Chapter 12 "Accessories".



Pos	Description
1	Suspension hook
2	Display (spray current and recipe)
3	Display standby
4	Operating button (standby and recipe change)
5	Protection against contact with union nut
6	Air cap for flat jet nozzle (see accessories in Chapter 12.2.1)
7	Flat jet nozzle ACF 5000 (see accessories in Chapter 12.2.2)
8	Adapter
9	Cover
10	Handle
11	Trigger lock

Pos	Description
12	Trigger lever
13	Round jet nozzle adapter (see accessories in Chapter 12.1.1)
14	Round jet nozzle insert (see accessories in Chapter 12.1.2)
15	Sealing plug
16	Air adjustment
17	Electric cable connection
18	Atomizing air connection
19	Product connection
20	Filter housing with filter
21	Type plate left
22	Type plate right



Note:

The gun type (T) on the type plate (21) and the serial number (S) on the underside of the handle.

5.1.2 FUNCTIONING OF THE SPRAY GUN

When the spray gun is connected to the control unit and the control unit is switched on, the pre-defined recipe (R1, R2 or R3) is shown on the gun display (2) as follows.


Recipe 1 -> ●○○○○ R1

Recipe 2 -> ●●●○○ R2

Recipe 3 -> ●●●●● R3

Recipe change R1 -> R2 -> R3 -> R1.

Press the operating button (4) and keep the button pressed of at least 2 seconds, then it is advanced by 1 recipe.



B_03182

Display (2) -> ●●○○○ = recipe values changed temporarily:
The stored recipe values of the previously selected recipe number are re-loaded from memory by pressing the operating button (4) for 2 seconds.

During spraying (trigger lever pressed), the status is shown in the display (2) by LEDs.


LED display	Description
LEDs 1 - 3 light up green	The spray gun is working in an optimal high-voltage spray current range
one or both right-hand LEDs light up orange (Warning display: You can continue working without any limitations.)	spray current too high Possible causes: <ul style="list-style-type: none"> ● Spray gun too close to the work piece ● Contamination of the spray gun ● Paint conductivity too high

OPERATING MANUAL




The trigger can be used to activate, one after the other, the various functions of the spray gun.

Distance	Description
1	AirCoat air opens.
2	AirCoat air opened and electrostatic (high-voltage) activated. Display (2) for "spray current" on the spray gun ●○○○○○ to ●●●●● activated.
3	AirCoat air opened and electrostatic (high-voltage) activated and product valve opened.
4	Overall way of trigger



B_03157

- An increase in the force needed to pull the trigger back will be perceived at the position where the product valve opens.
- For spraying without high-voltage, the high-voltage can be switched off using the operating button (4). Press the operating button (4) briefly: High-voltage is switched off. The standby display (3) illuminates.
- In the event of a malfunction the spray gun switches to "standby" operating mode and the display (3) blinks.
- The width of the spray jet can be adjusted using the air adjustment (16) (only for flat-jet method).



B_03262

5.2 SCOPE OF DELIVERY

Stk	Order No.	Description
1	2344473	GM 5000EAC spray gun Without control unit, product and air hose, electric cable, air cap and nozzle.

Each gun includes as standard equipment:

	Order No.	Description
1	2309368	Assembly tool valve needle
1	2325263	Assembly tool clamping screw
1	2319653	Protection gloves against spray mist
1	2316160	FM Control Document GM 5000E
1	see Chapter 1.3	Operating manual in local language


The spray gun basic version can be set according to requirement and the desired accessories by means of the spray gun configuration.

The delivery note shows the exact scope of delivery.


5.3 TECHNICAL DATA

Maximum air pressure	0.8 MPa; 8 bar; 116 psi
Maximum product pressure	25 MPa; 250 bar; 3,626 psi
Fluid inlet	NPSM 1/4"-18
Air connection	G 1/4" A
Input voltage	maximum 20 Vpp
Input current	maximum 1.0 A AC
Output voltage	maximum 70 kV DC
Output current	maximum 100 µA DC
Polarity	negative
Weight (without hose set)	710g (including union nut, nozzle, air cap and edge filter)
Operating temperature range	0 °C to 40 °C
	32 °F to 104 °F
Maximum product temperature	50°C
	122 °F
Sound level at 0.3 MPa; 3 bar; 43.5 psi air pressure and 11 MPa; 110 bar; 1,549 psi product pressure.	73 dB(A) *

* A-rated sound pressure level measured at 1 m distance, LpA1m, in accordance with DIN EN 14462: 2005.

Dimensions

GM 5000EAC F with flat jet nozzle		
	mm	inch
A	280	11.02
B	46	1.81
C	264	10.39




GM 5000EAC R with round jet nozzle		
	mm	inch
A	264	10.39
B	46	1.81
C	264	10.39

5.4 SPRAY PROCESS

5.4.1 AIRCOAT ROUND JET SPRAY PROCESS

In the AirCoat process, the spray product is atomized under a pressure of 3-15 MPa; 30-150 bar; 435-2,176 psi. With the help of an air pressure of 0-0.25 MPa; 0-2.5 bar; 0-36 psi, a soft, spray jet is produced. The spray jet diameter can be adjusted by turning the nozzle nut.




Advantages

- Large application volume
- Low fogging tendency
- Good finish
- High viscosity paints can easily be applied
- High endurance of the nozzles
- Jet width adjustment

5.4.2 AIRCOAT FLAT JET SPRAY PROCESS

In the AirCoat process, the spray product is atomized under a pressure of 3-15 MPa; 30-150 bar; 435-2,176 psi. With the help of the AirCoat air, with a pressure of 0-0.25 MPa; 0-2.5 bar; 0-36 psi, a soft, flat spray jet is produced which largely eliminates the problem of overlapping in the peripheral zones. With shaping air, there is the possibility of reducing the width of the spray jet.




Advantages

- Large application volume
- Low fogging tendency
- Good finish
- High viscosity paints can easily be applied
- High endurance of the AC-nozzles
- Jet width adjustment

5.4.3 ELECTROSTATIC EFFECT

The spray gun produces an electrostatic field by means of the high-voltage electrode. As a result, the paint particles atomized by the spray gun are carried to the grounded work piece by kinetic and electrostatic energy where they adhere finely dispersed to the object to be sprayed.



Advantages

- Very high application effectiveness
- Low over spray
- Coating of entire circumferences due to the electrostatic effect
- Savings in working time

6 COMMISSIONING AND OPERATION

6.1 TRAINING ASSEMBLY/COMMISSIONING STAFF

	 WARNING
	<p>Incorrect installation/operation! Risk of injury and equipment damage.</p> <ul style="list-style-type: none"> → The commissioning staff must have the technical skills to safely undertake commissioning. → When commissioning and for all work, read and follow the operating manual and safety regulations for the additionally required system components.

6.2 STORAGE CONDITIONS

Until the point of assembly, the manual spray gun must be stored in a dry location, free from vibrations and with a minimum of dust. The manual spray gun must be stored in closed rooms.

The air temperature at the storage location must be between -20 - +60 °C; -4 - +140 °F.

The relative air humidity at the storage location must be between 10 and 95 % (without condensation).


6.3 INSTALLATION CONDITIONS

The air temperature at the installation site must be between 0 - 40 °C; 32 - 132 °F.

The relative air humidity at the installation site must be between 10 and 95 % (without condensation).

6.4 INSTALLATION AND CONNECTION

6.4.1 TYPICAL ELECTROSTATIC SPRAYING SYSTEM



B_03158

Pos	Description
1	GM 5000EACF spray gun
2	Gun cable
3	Grounding cable
4	Pneumatic pump
5	Trolley
6	Pressure regulator + air filter
7	Product suction system
8	Return hose
9	High-pressure filter
10	Compressed air connection

Pos	Description
11	Stop valve
12	Air pressure regulator
13	VM 5000 control unit
14	Protective hose
15	Air hose
16	Product hose
17	Return valve
18	Tank for return flow

Pos	Description
19	Paint tank
20	Tank, cleaning agent
21	Power cable

The GM 5000EAC spray gun must be used as part of a spraying system (Spraypack). The system shown in figure B_03158 is only one example of an electrostatic spraying system. Your WAGNER distributor would be happy to assist you in creating a spraying system solution that meets your individual needs. You must familiarize yourself with the operating instructions and the safety regulations of all additional system components before starting commissioning.

	 WARNING
	<p>Incorrect installation/operation! Risk of injury and equipment damage.</p> <p>→ When commissioning and for all work, read and follow the operating manual and safety regulations for the additionally required system components.</p>

6.4.2 VENTILATION OF THE SPRAY BOOTH

The electrostatic hand spraying equipment is for use only in spray areas which correspond with standard EN 12215.

The electrostatic hand spraying equipment has to be locked to the technical ventilation so that the coating product supply and the high-voltage are not effective as long as the technical ventilation is not operated with the minimum exhaust air volume flow or a larger exhaust air volume flow.

Ensure that the excess coating product (overspray) will be collected up safely.

	 WARNING
	<p>Toxic and/or flammable vapor mixtures! Risk of poisoning and burns.</p> <p>→ Operate the device in a spray booth approved for the working products. -or- → Operate the device on an appropriate spraying wall with the ventilation (extraction) switched on. → Observe national and local regulations for the outgoing air speed.</p>

6.4.3 AIR SUPPLY

The use of an air filter with the air regulator (6) ensures that only dry, clean atomizing air gets into the spray gun. Dirt and moisture in the atomizing air worsens the spraying quality and spraying pattern.

6.4.4 MATERIAL SUPPLY

NOTICE

Impurities in the spraying system!

Spray gun blockage, products harden in the spraying system.

→ Flush the spray gun and paint supply with a suitable cleaning agent.



DANGER

Bursting hose, bursting threaded joints!

Danger to life from injection of product.

- Ensure that the hose material is chemically resistant to the sprayed products.
- Ensure that the spray gun, threaded joints, and product hose between the device and the spray gun are suitable for the pressure generated in the device.
- Ensure that the following information can be seen on the high-pressure hose:
 - Manufacturer
 - Permissible operating pressure
 - Date of manufacture



WARNING

Hose connections

Risk of injury and equipment damage.

- Do not exchange hose connections of product hose and air hose.

6.4.5 GROUNDING

Perfect grounding of all conductive parts such as floors, walls, roofs is important for optimum coating and safety. Barriers, work pieces, transport devices, coating product tank, coating product supply or construction parts in the spray area with exception of the high-voltage parts during normal operation.

Parts of the booth must be grounded in accordance with EN 12215.

	 WARNING
	<p>Discharge of electrostatically charged components in atmospheres containing solvents! Explosion hazard from electrostatic sparks or flames.</p> <p>→ Ground all device components. → Ground the work pieces to be coated.</p>

	 WARNING
	<p>Heavy paint mist if grounding is insufficient! Danger of poisoning. Insufficient paint application quality.</p> <p>→ Ground all device components. → Ground the work pieces to be coated.</p>

A poorly grounded work piece causes:

- very bad wrap around,
- uneven coating,
- back spraying to the spray gun, i.e. contamination.

Prerequisites for perfect grounding and coating are:


- Clean work piece suspension.
- Grounding of spray booth, conveyor system and suspension on the building side in accordance with the operating instruction or the manufacturer's information.
- Grounding of all conductive parts within the working area.
- The grounding resistance of the work piece may not exceed 1 MΩ (Megohm).

Note:


Resistance to ground measured at 500 V or 1,000 V.

- Connect the control unit to the system ground.

Grounding schema (example):



Minimum cable cross-section	
Control unit	4 mm ² (AWG 12)
Pump	4 mm ² (AWG 12)
Paint tank	4 mm ² (AWG 12)
Conveyor	16 mm ² (AWG 6)
Booth	16 mm ² (AWG 6)
Spraying stand	16 mm ² (AWG 6)



A series of horizontal lines for writing notes, starting from the top right of the notepad icon and extending across the page.

6.5 PREPARATION OF LACQUER

The viscosity of the lacquers is of great importance. The best spraying results are obtained with values between 25 and 40 DIN-s (measured in immersion flow cup DIN 4 mm; 0.16 inch). Processing of up to 60 DIN-s is generally possible without problem, if high coating thicknesses are required.

With the Wagner AirCoat flat jet spraying process, the different viscosities of the lacquer are optimally covered by two air cap types. These can be found in "Accessories".

In the case of application problems contact the paint producer.

6.5.1 VISCOSITY CONVERSION TABLE

milli Pascal x x Sec mPas	Centipoise	Poise	DIN Cup 4 mm 0.16 inch	Ford Cup 4	Zahn 2
10	10	0.1		5	16
15	15	0.15		8	17
20	20	0.2		10	18
25	25	0.25	14	12	19
30	30	0.3	15	14	20
40	40	0.4	17	18	22
50	50	0.5	19	22	24
60	60	0.6	21	26	27
70	70	0.7	23	28	30
80	80	0.8	25	31	34
90	90	0.9	28	32	37
100	100	1	30	34	41
120	120	1.2	33	41	49
140	140	1.4	37	45	58
160	160	1.6	43	50	66
180	180	1.8	46	54	74
200	200	2	49	58	82
220	220	2.2	52	62	
240	240	2.4	56	65	
260	260	2.6	62	68	
280	280	2.8	65	70	
300	300	3	70	74	
320	320	3.2			
340	340	3.4			
360	360	3.6	80		
380	380	3.8			
400	400	4	90		

6.6 COMMISSIONING

6.6.1 GENERAL RULES FOR MANIPULATION OF THE SPRAY GUN

→ Observe safety instructions in Chapter 4.

	 DANGER
	<p>High-voltage field! Danger to life from malfunction of heart pacemakers.</p> <p>Make sure that persons with pace makers:</p> <ul style="list-style-type: none"> → Do not work with the electrostatic spray gun. → Stay outside the area of the electrostatic spray gun/work piece.

	 WARNING
	<p>Unintentional putting into operation! Risk of injury.</p> <p>Before any work on the device, in the event of work interruptions and malfunctions:</p> <ul style="list-style-type: none"> → Switch off the energy/compressed air supply. → Relieve the pressure from the spray gun and unit. → Secure the spray gun against actuation. → In the event of functional faults: remedy the fault as described in the "Troubleshooting" chapter.

6.6.2 PREPARATION FOR STARTING UP

The following points should be noted before commissioning

- Grounding see Chapter 6.4.5. Make sure that all other conductive parts within the work area are grounded.
- Connect the product hose to spray gun and product pump.
- Check that all product-conveying connections are correctly connected
- Connect air hose to spray gun and to supply of oil-free dry air, approx. 0.25 MPa; 2.5 bar; 36 psi. Compressed air quality class 3.5.2 according to ISO 8573.1.
- Check that all air-conveying connections are correctly connected.
- Connect the electric cable to the spray gun and to the VM 5000 or VM 500 control unit.
- Visually check the permissible pressures for all the system components.
- Check the level of the separating agent in the Wagner pneumatic pump and fill the separating agent up if necessary.

- Provide product tank, tanks for flushing agent and an empty tank for return.
- Connect the system with a secured gun to the air and power supply.
- A basic flushing of system must be carried out before commissioning.
Make sure that no nozzle is inserted into the gun.

	 WARNING
	<p>Sparks form when the plug is removed! Explosion hazard.</p> <p>When using the spray gun in explosion hazard areas: → The cable connection on the gun and the connection to any cable extensions may not be disconnected or connected in this area.</p>

Attention: gun cable to control unit

Secure the cover sleeve with the warning sign by means of the screw (84) on the connector.



B_03691


Attention: guns with electric extension cable

Secure the cover sleeves with the warning sign by means of the screws (84) on the connectors.

Note:

In order to prevent power losses, keep the cable length as short as possible. The maximum power is available with the standard cable length of 10 m.

An extension to a total length of up to 40 m will cause a power loss of up to 10%. The gun cable can be extended to a total length of 80 m, however, a power loss of up to 30 % will be caused.



7 OPERATION


7.1 TRAINING THE OPERATING STAFF

	 WARNING
	<p>Incorrect operation! Risk of injury and equipment damage.</p> <ul style="list-style-type: none"> → The operating staff must be qualified to operate the entire system. → Before work commences, the operating staff must receive appropriate training.

7.2 SAFETY INSTRUCTIONS

	 WARNING
	<p>Incorrect operation! Risk of injury and equipment damage.</p> <ul style="list-style-type: none"> → If contact with solvent-based paints or cleaning agents causes skin irritation, appropriate precautionary measures must be taken, e.g. wearing protective clothing. → The footwear worn by operating staff must comply with EN ISO 20344. The measured insulation resistance must not exceed 100 MΩ. → The protective clothing, including gloves, must comply with EN ISO 1149-5. The measured insulation resistance must not exceed 100 MΩ.

	 WARNING
	<p>Discharge of electrostatically charged components in atmospheres containing solvents! Explosion hazard from electrostatic spark-over.</p> <ul style="list-style-type: none"> → Use gun only with fitted nozzle, air cap and union nut. → Tighten the union nut, especially with nozzle in the cleaning position.



7.3 WORK

7.3.1 FILLING WITH WORKING PRODUCT

1. Place an empty tank (18) under the return tube (8) (see picture B_03158).
2. Place suction hose (7) in the tank with working product (19).

Note:

If the pump is equipped with a rigid suction system, it should only be dipped in into the working product up to the middle of the inlet housing at the maximum!

3. Adjust the pressure regulator (12) to approx. 0.05 MPa; 0.5 bar; 7.25 psi.
4. Open return valve (17).
5. Slowly open the ball valve (11).
6. Adjust the air pressure on the pressure regulator (12) so that the pump runs smoothly.
7. Close ball valve (11) as soon as pure working product starts coming from the return tube (8).

8. Close return valve (17).
9. Point the gun, without nozzle, into tank (18) and open it.
10. Slowly open the ball valve (11).
11. Close ball valve (11) as soon as pure working product starts coming from the gun.
12. When there is no pressure remaining in the system, close the gun.
13. Secure the gun.
14. Dispose of the contents of the tank (18) according to the local regulations.

7.3.2 START-UP FOR SPRAYING AIRCOAT

1. Secure gun and insert the desired nozzle into the gun.
2. Set pump (4) to about 8 Mpa; 80 bar; 1,160 psi operating pressure and start up control unit (13).
3. Spraying (pull trigger).
4. Adjust the spray pressure at the paint pump according to the nozzle and object being sprayed
5. Now open AirCoat air (6), approx. 0.01-0.25 MPa; 1-2.5 bar; 14,5-36 psi, and adjust for the optimal atomization.


For round-jet method:

6. By turning the nozzle nut, the atomizing air jet can additionally be adjusted.

Notes:

Do not turn the nozzle nut until it is flush with the nozzle body. There must be play for the atomizing air between the nozzle nut and the nozzle body.


The air adjustment at the back of the gun does not affect the spray pattern in this process.



B_03192

For flat-jet method:

7. Change the width of the spray jet by turning the air adjustment on the back of the spray gun or by appropriate selection of the nozzle.




B_03159

7.3.3 FLUSHING OUT CLOGGED ROUND JET NOZZLES


	 DANGER
	<p>Exploding gas / air mixture! Danger to life from flying parts and burns.</p> <p>→ Never spray into a closed tank. → Ground the tank.</p>

1. Use nozzle spanner (2) to loosen nozzle insert (1) by a half turn.
2. Remove the nozzle spanner and briefly actuate trigger.
3. After flushing the nozzle, re-tighten the nozzle insert.





7.3.4 REPLACING ROUND JET NOZZLE'S NOZZLE INSERT

1. Remove nozzle insert (1) using nozzle spanner (2).
2. Assembling new nozzle insert.



7.3.5 CHANGING FROM AIRCOAT ROUND JET TO AIRCOAT FLAT JET

1. Flush the spray gun (1) out thoroughly with cleaning agent.
2. Relieve the pressure of gun and device.
3. Secure the spray gun (1) using the trigger lock.
4. Unscrew round jet nozzle cap (2) incl. nozzle insert (3).
5. Unscrew nozzle insert (3) using nozzle spanner (4).
6. Unscrew nozzle nut (5) and remove nozzle screw connection (7) and sealing fitting (8) out off the nozzle body (6) and clean all parts thoroughly.
7. Insert desired ACF 5000 nozzle (11) into the valve housing.
8. Put the air cap (10) on the nozzle (11) and pay attention to the position of the guide surfaces.
9. Screw union nut with attached nozzle guard (9) to the gun body and make sure that the air cap horns lie in the designated recess (Y).
10. Before tightening with the air cap horns (Y), set the desired jet level and then tighten the union nut to stop by hand.



B_03162

7.3.6 REPLACING THE AIRCOAT FLAT JET NOZZLES

1. Switch off control unit.
2. Relieve pressure from the gun (1) and from the device!
3. Secure the spray gun (1) using the trigger lock.
4. Unscrew union nut (12) and remove air cap (10).
5. Remove ACF5000 AirCoat nozzle (11) and treat it with cleaning agent until all traces of paint have been removed.

NOTICE

Defective AirCoat nozzle!

Insufficient paint application quality.

→ Do not use sharp-edged objects to treat carbide on the AirCoat nozzle.

6. Insert new ACF5000 nozzle (11) into the valve housing.
7. Put the air cap (10) on the nozzle (11) and pay attention to the position of the guide surfaces.
8. Screw union nut with attached nozzle guard (9) to the gun body and make sure that the air cap horns lie in the designated recess (Y).
9. Before tightening with the air cap horns (Y), set the desired jet level and then tighten the union nut to stop by hand.

7.3.7 CLEANING OF THE NOZZLE PARTS

The ACF5000 AirCoat nozzles (11), the nozzle inserts (3) and the nozzle screw connection (7) can be placed in a cleaning solvent recommended by the lacquer manufacturer.


All other nozzle parts may **not be put into cleaning solvent**.

Clean these parts with a cleaning solvent recommended by the lacquer manufacturer and dry with a cloth or blow gun.

7.3.8 ELIMINATE NOZZLE CLOGGING

1. Switch off control unit.
2. Relieve the pressure of gun and device.
3. Secure the spray gun (1) using the trigger lock (14).
4. Unscrew complete union nut (12) with air cap (10) and ACF5000 nozzle (11).
5. Remove air cap (10).
6. Push ACF 5000 nozzle (11) out of air cap (10) by hand, reverse it and put it into the air cap (10) with the nozzle tip towards the rear.
Pay attention to the position of the guide surfaces (X).
7. Insert air cap (10) with integrated ACF5000 nozzle (11) into the union nut (9).
Make sure that the air cap horns (Y) lie in the recess of the nozzle guard.

8. Screw preassembled union nut (12) to gun (1) and tighten by hand.
9. Switch the product pressure back on.
10. Turn the trigger lock (14) to the spraying position and briefly pull the trigger.
11. When the blockage has been flushed out, secure the gun with the trigger lock.
12. Relieve the pressure of gun and device.
13. Unscrew union nut (12).
14. Remove air cap (10) and push ACF5000 nozzle (11) out of the air cap by hand.
Clean ACF5000 nozzle and insert it in the spraying position into the valve housing.
15. Put the air cap (10) on the nozzle (11) and pay attention to the position of the guide surfaces (X).
16. Screw union nut with attached nozzle guard (9) to the gun body and make sure that the air cap horns lie in the designated recess (Y).
17. Before tightening with the air cap horns (Y), set the desired jet level and then tighten the union nut to stop by hand.
18. Switch the product pressure and the air pressure back on.
19. Switch on the control unit.



7.3.9 CHANGING THE VALVE HOUSING


NOTICE

Changing the valve housing!

Equipment damage.

→ Activate the spray gun trigger when changing the valve housing.

To prevent damage to the gun (valve seat rubs on the valve needle, valve needle may loosen), activate the spray gun trigger when changing the valve housing.



B_03847

8 CLEANING AND MAINTENANCE

8.1 CLEANING

8.1.1 CLEANING STAFF

Cleaning work should be undertaken regularly and carefully by qualified and trained staff. They should be informed of specific hazards during their training.

The following hazards may arise during cleaning work:

- Health hazard from inhaling solvent vapors
- Use of unsuitable cleaning tools and aids

8.1.2 SAFETY INSTRUCTIONS

	 <b style="font-size: 1.2em;">DANGER
	<p>Explosive powder/air mixes! Danger to life and equipment damage.</p> <ul style="list-style-type: none"> → Before starting cleaning or other manual work, the high-voltage must be shut down and locked to prevent it from being switched back on! → The spray gun must be separated from the high-voltage supply before any cleaning work is started! → Use only electrically conductive tanks for cleaning liquids! Ground the tank! → Preference should be given to non-flammable cleaning fluids. → Only cleaning agents of explosion class IIA should be used (maximum ignition energy 0.24 mJ). → The cleaning agent's flash point must be at least 15 K above the ambient temperature. → Ensure that no electric component is cleaned with or immersed into solvent.

8.1.3 CLEANING AND DECOMMISSIONING

The spray gun and the unit must be cleaned daily. The cleaning agents used for cleaning must correspond with the working product.

Cleaning of the nozzle parts -> Chapter 7.3.7

Eliminating Nozzle Clogging -> Chapter 7.3.8

NOTICE

Flushing agent in the air duct!

Functional faults caused by swollen seals.

→ Never immerse the spray gun in cleaning agent.



WARNING

Incorrect maintenance/repair!

Risk of injury and equipment damage.

- Have repairs and part replacements be carried out only by specially trained staff or a WAGNER service center.
- Before all work on the device and in the event of work interruptions:
 - Switch off the energy/compressed air supply.
 - Relieve the pressure from the spray gun and device.
 - Secure the spray gun against actuation.
- Observe the operating instructions for any work.

	 DANGER
	<p>Exploding gas / air mixture! Danger to life from flying parts and burns.</p> <p>→ Never spray into a closed tank. → Ground the tank.</p>

Gun flushing

1. Switch off control unit.
2. Ensure that the product pressure is relieved and shut off the air supply to the gun.
3. Connect the cleaning agent supply.

With round jet nozzle fitted:

 4. By means of nozzle spanner, loosen nozzle insert by 1/2 turn.
 5. Actuate the trigger. Flush the gun thoroughly.
 6. Relieve the pressure from gun and unit!
 7. Re-tighten the nozzle insert.
 8. Clean the spray gun body with a cleaning agent recommended by the manufacturer and dry with a cloth or blow gun.

With flat jet nozzle fitted:


 4. Dismount AirCoat nozzle and clean separately (see Chapter 7.3.7).
 5. Actuate the trigger. Flush the gun through thoroughly.
 6. Relieve the pressure from gun and unit!
 7. Clean the spray gun body with a cleaning agent recommended by the lacquer manufacturer and dry with a cloth or blow gun.

NOTICE

Flushing agent in the air duct!

Functional faults caused by swollen seals.
Discharge current to ground -> no high-voltage

- Always point the spray gun down when cleaning.
- Ensure that neither paint nor cleaning agent enters the air duct.
- When taking a break from work or when stored for a longer period, the spray gun should be positioned with the adapter pointing downwards.



B_03453

8.2 MAINTENANCE

8.2.1 MAINTENANCE STAFF

Maintenance work should be undertaken regularly and carefully by qualified and trained staff. They should be informed of specific hazards during their training.

The following hazards may arise during maintenance work:

- Health hazard from inhaling solvent vapors
- Use of unsuitable tools and aids

Once the maintenance work is complete, the device must be checked by a qualified person to ensure a reliable condition.

8.2.2 SAFETY INSTRUCTIONS

	 DANGER
	<p>Incorrect maintenance/repair! Danger to life and equipment damage.</p> <p>→ Repair or replacement of devices or parts of devices are only allowed to be performed outside the hazard area by qualified personnel.</p>

Check hoses, pipes, and couplings every day and replace if necessary.

- In accordance with the guideline for liquid ejection devices (ZH 1/406 and BGR 500 Part 2 Chapter 2.36):
- The liquid ejection devices should be checked by an expert (e.g. Wagner service technician) for their safe working conditions as required and at least every 12 months.
 - If devices have been decommissioned, the examination can be suspended until the next start-up.



DANGER

Incorrect maintenance/repair!

Danger to life and equipment damage.

- Only a WAGNER service center or a suitably trained person may carry out repairs and replace parts.
- Only repair and replace parts that are listed in the "Spare Parts" chapter and that are assigned to the device.
- Before all work on the device and in the event of work interruptions:
 - Disconnect the control unit from the mains.
 - Relieve the pressure from the spray gun and device.
 - Secure the spray gun against actuation.
- Observe the operating manual and service instructions at all times when carrying out work.

8.3 DISASSEMBLY OF THE SPRAY GUN


8.3.1 TOOLS

For disassembling and assembling the gun the following tools are required:


●	Allen wrench SW 2
●	Allen wrench SW 3
●	Allen wrench SW 5
●	Open-end wrench SW 5
●	Open-end wrench SW 6
●	Open-end wrench SW 8
●	Open-end wrench SW 11
●	Open-end wrench SW 12
●	Open-end wrench SW 14
●	Open-end wrench SW 19
●	Open-end wrench SW 21
●	Open-end wrench SW 22
●	Ring spanner SW 9
●	Torx wrench 20
●	Torx wrench 25
●	Assembly tool valve needle Order No. 2309368
●	Assembly tool clamping screw Order No. 2325263

8.3.2 DISASSEMBLY OF THE SPRAY GUN


1




2



3




4




Note:
If the fitting (25) is not on the dismantled product hose when it is replaced, the fitting must be removed from the gun adapter.

Note:
Loosen AC valve tip by hand using an assembly tool.




5



6




7




1. Remove pressure spring (4).
2. Loosen clamping screw compl. (1) with assembly tool (5).
3. Unscrew the complete packing (3) via valve rod unit complete (2, 6 and 7) or pull out the valve rod unit and unscrew it using an Allen wrench SW5.
4. If the loosened packing (3) is jammed in the hole, push from the front (see illustration above).

B_03198

8



9



1. Loosen the oval head screw (1).
2. Pull the air valve (2) out off the hole.

B_03199

8.4 CLEANING THE PARTS AFTER DISASSEMBLY

ATTENTION


Please note:

- All reusable parts (except for the parts conducting high-voltage such as cascade, adapter, plug compl. etc.) should be cleaned thoroughly using a suitable cleaning agent.
- The adapter, plug compl. and the handle inside must be clean and dry after cleaning. Care should be taken that these parts remain free of solvents, grease or sweat from the hands (salt water).
- Spare parts may have safety-relevant properties.
- Use only WAGNER original spare parts and accessories.
- Defective parts, O-rings and seal sets must always be re-placed.


	 WARNING
	<p>Incompatibility of cleaning agent and working medium! Risk of explosion and danger of poisoning by toxic gasses.</p> <p>→ Examine the compatibility of the cleaning agents and working media on the basis of the safety data sheets.</p>

In Chapter 13 the part numbers for gun spare parts can be found as well as for wearing parts such as seals.


8.5 ASSEMBLY OF THE SPRAY GUN



1




2





Assembly aids:		
Pos	Order No.	Description
1	9992590	Loctite 222
2	9992698	Vaseline white PHHV II
3	9992831	Loctite 542
4	9992511	Loctite 243
5	9992609	Anti-seize paste

3



Set measure X with withdrawal nut and then fasten it with the threaded pin (SW2).



Push the valve rod unit and the complete packing together.


Screw the valve rod unit and the complete packing together.

Only as required:
Remove the valve rod unit.
Tighten the complete packing.

Carefully insert the valve rod unit and mount the complete clamping screw (1) with assembly tool (5).


B_03202

4



Slightly tighten AC valve tip by hand using an assembly tool (Order No. 2309368).


5



B_03203

6


Clean and degrease the inside of the adapter and the cascade, then grease the cascade surface with Vaseline.



Note:


Before assembling the product hose, check that no fitting (25) is in the gun adapter!
Check the fitting for damage and replace if necessary (Order No. 2338853).

7




8


Push the trigger upward into the air valve piston.



9



10



Flat jet nozzle
Assembly see Chapter 13.3.1.
Various nozzle sizes see Chapter 12.2

Round jet nozzle
Assembly see Chapter 13.3.2.
Various nozzle sizes see Chapter 12.1.

B_03208

8.6 FUNCTION TEST AFTER ASSEMBLY OF THE GUN

8.6.1 TEST OF THE HIGH-VOLTAGE

Necessary test equipment:

VM 500 or VM 5000 control unit and HV200 high-voltage tester.

High-voltage measurement on spraying gun.

Connect gun cable to control unit. Take the spray gun in your hand and hold into open space. Switch on control unit and actuate trigger guard.

The high-voltage should be 50 to 60 kV in dry ambient air. The value can be checked with the display on the control unit (VM 5000).

Notice

The gun must be clean and dry and must not have any color or cleaning agent residues.

In the case of ambient air with a high air humidity, the measured value can reduce to 40 to 50 kV.

High-voltage measurement with high-voltage tester

Place the ball of the high-voltage tester on the gun electrode and turn on the high-voltage. The measured value should be 60 to 70 kV.


Notes

- When measuring the high-voltage the gun and the measuring device should be held at arms length as far from the body as possible.
- There should be no chargeable objects within a radius of 1 m; 3.28 ft of the place where the measurements are taken.
- The placing of the measuring ball of the high-voltage measuring device reduces the spraying of the high-voltage electrode. As a result the high-voltage value increases compared to the spraying in the free space.

Disruptive discharge test

Check the gun against ground with the grounding rod. No sparks should be formed.

Note: in the vicinity of the electrode harmless corona discharges can occur.



8.6.2 AIR TEST

Connect test or air hose to the spray gun and switch on mains pressure to a maximum of 0.8 MPa; 8 bar; 116 psi.


Checking the air valve

The air valve must switch on and off correctly.

Test up to approx. 0.8 MPa; 8 bar; 116 psi.

Air tightness

With the trigger unactuated, test for air tightness at the points marked in the illustration:



8.6.3 PRODUCT PRESSURE TEST

Connect high-pressure hose to the spray gun.

Test the spray gun for tightness with solvent or spray oil (e.g. Macrol 52) and a maximum pressure of 25 MPa; 250 bar; 3,626 psi.

Observe the following gun components:

Product connection, nozzle body, product valve (no after-spraying).

		<h2>DANGER</h2>
	<p>Exploding gas / air mixture! Danger to life from flying parts and burns.</p> <ul style="list-style-type: none"> → Never spray into a closed tank. → Ground the tank. 	

8.6.4 TEST OF SPRAY PATTERN


Start AirCoat spraying (without electrostatics)

1. Start up with product supply set to approx. 8 MPa; 80 bar; 1,160 psi operating pressure.
2. Spray (release locking device and pull trigger) and at the same time, check the atomization.
3. Set the product pressure on the product supply to the point where a good product atomization is achieved.
4. Open the air pressure regulator for the atomizing air and adjust it so that an optimal atomization is achieved. (The interrelation between spray pattern and atomizing air is shown in the figure below).
5. With the air adjustment on the gun, set the ratio shaping air / atomizing air so as to achieve an optimum spray pattern.

Note:

Repeat points 4 and 5 until the optimum spray pattern is reached (iterative process).

Spray pattern shapes




Notice

The paint output can be changed by:

- changing the product pressure or
- using a different flat jet nozzle (see Chapter 12.2).

Influence of the air adjustment on the spray pattern shape

The spray pattern can be adjusted to suit the object to be sprayed using the air adjustment. The illustration shows the influence of the shaping air regulator on the spraying pattern. Other nozzle sizes can be used to obtain larger or smaller spraying patterns.



8.7 HIGH-PRESSURE HOSES

The service life of the fluid hoses is reduced due to environmental influences even when handled correctly.

- Check hoses, pipes, and couplings every day and replace if necessary.
- As a precaution, fluid hoses should be replaced after a period specified by the operator.

	 DANGER
	<p>Bursting hose, bursting threaded joints! Danger to life from injection of product.</p> <ul style="list-style-type: none">→ Ensure that the hose material is chemically resistant to the sprayed products.→ Ensure that the spray gun, threaded joints, and product hose between the device and the spray gun are suitable for the pressure generated in the device.→ Ensure that the following information can be seen on the high-pressure hose:<ul style="list-style-type: none">- Manufacturer- Permissible operating pressure- Date of manufacture

9 INSPECTIONS

→ Observe safety instructions in Chapter 4.

9.1 PERIODICAL INSPECTIONS

For the safe operation of electrostatic manual coating systems for flammable liquid coating products, intervals for periodical inspections are defined as follows:

Inspection point	Inspection interval	Remarks
Gun cleaning, gun flushing	daily	Chapter 4.2.4, Chapter 8.1.3
Hoses, tubes, couplings	daily	Chapter 8.7
Grounding	weekly	Chapter 4.2.2, Chapter 6.4.5
Inspection for damage	weekly	Chapters 8.1.3, 8.2, 8.3, 8.4 and 8.5
Locking of the technical ventilation with the electrostatic manual coating system	annually	Chapter 6.4.2


The above recommended intervals are maximum values and may be modified by the operator depending on the local and operational conditions and the contamination.

Damaged devices must be decommissioned and repaired immediately.

10 TROUBLESHOOTING AND RECTIFICATION

Functional fault	Cause	Remedy
Insufficient product output	Nozzle too small.	Select larger nozzle (see nozzle table 12.2 und 12.3).
	Product pressure too low.	Increase product pressure.
	Gun filter or high pressure filter clogged at pump.	Clean or replace filter.
	Nozzle is clogged.	Nozzle cleaning (see Chapters 7.3.3 to 7.3.8).
Poor spray pattern	Atomizing air incorrectly adjusted.	Readjust the atomizing air.
	Nozzle is too large.	Select a smaller nozzle (see nozzle table).
	Product pressure too low.	Increase the product pressure at pump.
	The product viscosity is too high.	Thin product in accordance with the manufacturer's instructions.
Valve rod leaks	Seals at the valve rod are damaged.	Replace the seals (see Chapter 8).
	Loose packing	Tighten
Poor wrap-around	Insufficient grounding.	Check grounding.
	Inadequate electric resistance of the lacquer.	Check lacquer resistance (see Chapter 2.5).
	Spraying pressure too high.	Readjust spraying pressure.
Back-spray	No grounding	Check grounding.
	Distance between spray gun and work piece too large.	Reduce distance between spray gun and work piece.
	Nozzle nut placed too far forward	Move nozzle nut back (Decrease air distributor ring gap).
No wrap-around	High-voltage switched off.	Switch on the high-voltage switch.
	No electrostatics.	Repair malfunction as laid down in the control unit operating instructions.

11 PRODUCT DISPOSAL


	<p style="text-align: center;">NOTICE</p> <p>Do not dispose of used electrical equipment with household refuse!</p> <p>In accordance with European Directive 2002/96/EC on the disposal of used electrical equipment and its implementation in national law, this product may not be disposed of with the household refuse, but must be recycled in an environmentally correct manner.</p> <p>Wagner or one of our dealers will take back your used Wagner electric or electronic equipment and will dispose of it for you in an environmentally-friendly way. Please contact one of our service points, one of our representatives or us directly to arrange this.</p>
---	---

12 ACCESSORIES

12.1 ROUND JET NOZZLES

12.1.1 ACR 5000 ROUND JET NOZZLE CAP


Order No.	Designation
2344483	ACR 5000 round jet nozzle cap (with nozzle spanner, without AC round jet nozzle insert)



12.1.2 AIRCOAT ROUND JET NOZZLE INSERTS

The round jet nozzles are especially suited to spray pipes, profiles and complex work pieces.

Order No.	Marking	Jet width mm; inch	Recommended gun filter
132720	11	approx. 250; 10	Red 200 meshes
132721	12	approx. 250; 10	
132722	13	approx. 250; 10	
132723	14	approx. 250; 10	
132724 *	15	approx. 250; 10	Yellow 100 meshes
132725	16	approx. 250; 10	
132726	17	approx. 250; 10	
132727	18	approx. 250; 10	
132728	19	approx. 250; 10	white 50 meshes
132729	20	approx. 250; 10	
132730	21	approx. 250; 10	
132731	22	approx. 250; 10	



* Standard version

Jet width in mm; inches at a distance of 30 cm; 11.8 inches from the object and at a pressure of 10 MPa; 100 bar; 1,450 psi.

12.2 FLAT JET NOZZLES

12.2.1 ACF 5000 AIR CAPS (FLAT JET)

Order No.	Designation
2309882	ACF 5000 air cap - LV suitable for low viscosity products (marked red)
2314203	ACF 5000 air cap - HV suitable for high viscosity products (marked blue)



12.2.2 ACF5000 AIRCOAT FLAT JET NOZZLES

Order No.	Marking	Bore Ø mm; inch	Spray angle	Application
				
395107	07/10	0.18; 0.007	10°	Natural lacquer
395207	07/20		20°	
395407	07/40		40°	
395109	09/10	0.23; 0.009	10°	Clear lacquer Oils
395209	09/20		20°	
395309	09/30		30°	
395409	09/40		40°	
395509	09/50		50°	
395609	09/60		60°	
395111	11/10	0.28; 0.011	10°	Synthetic resin lacquer PVC lacquer
395211	11/20		20°	
395311	11/30		30°	
395411	11/40		40°	
395511	11/50		50°	
395611	11/60		60°	
395811	11/80		80°	
395113	13/10	0.33; 0.013	10°	Lacquer Base coat Primer Filler
395213	13/20		20°	
395313	13/30		30°	
395413	13/40		40°	
395513	13/50		50°	
395613	13/60		60°	
395813	13/80		80°	
395115	15/10	0.38; 0.015	10°	Filler Rust proofing paints
395215	15/20		20°	
395315	15/30		30°	
395415	15/40		40°	
395515	15/50		50°	
395615	15/60		60°	
395815	15/80		80°	
395217	17/20	0.43; 0.017	20°	Rust proofing paints Latex paints
395317	17/30		30°	
395417	17/40		40°	
395517	17/50		50°	
395617	17/60		60°	
395817	17/80		80°	

Order No.	Marking	Bore Ø mm; inch	Spray angle	Application
				
395219	19/20	0.48; 0.019	20°	Rust proofing paints Latex paints
395319	19/30		30°	
395419	19/40		40°	
395519	19/50		50°	
395619	19/60		60°	
395819	19/80		80°	
395221	21/20	0.53; 0.021	20°	Mica paints Zinc rich paints Rust proofing paints Glue paints
395421	21/40		40°	
395521	21/50		50°	
395621	21/60	0.58; 0.023	60°	
395821	21/80		80°	
395423	23/40		40°	
395623	23/60	0.64; 0.025	60°	
395823	23/80		80°	
395425	25/40		40°	
395625	25/60	0.69; 0.027	60°	
395825	25/80		80°	
395427	27/40		40°	
395627	27/60	0.75; 0.029	60°	
395827	27/80		80°	
395429	29/40		40°	
395629	29/60	0.79; 0.031	60°	
395829	29/80		80°	
395431	31/40		40°	
395631	31/60	0.90; 0.035	60°	
395831	31/80		80°	
395435	35/40		40°	
395635	35/60	0.90; 0.035	60°	
395835	35/80		80°	

12.3 FILTER

Order No.	Designation
L011-888	Edge filter 60 mesh
L011-906	Edge filter 100 mesh
L011-907	Edge filter 200 mesh



B_00019

12.4 REDUCTION FITTINGS FOR HIGH-PRESSURE HOSES

The classification of WAGNER fittings is consistent with the following classification, each separated by high-pressure and low pressure fittings:


DF	Double fitting - male / male thread
RF	Reduction fitting - female / male thread
SF	Adjustable screw - female / male thread: allows precise angle adjustment (swivel)
EF	90° elbow - adjustable or male / male thread (elbow fitting)
BF	Bulkhead fastener - male / male thread with pressure-resistant feed-through
PF	Stopper - male thread for closing (plug fitting)
HF	Hose fitting with union nut and sealing cone (hose fitting)

The short description of the fittings are as follows:

DF-	MM-	G3/4"-	1/4"NPS-	PN270-	SSt
					Materials, SSt = Stainless steel
					Nominal pressure (in bar)
					1st thread, e.g. G1/4", 1/4"NPS
					2nd thread, e.g. G1/4", 1/4"NPS, M16x1.5
					M: male (outer thread) F: female (interior thread)

Short description see table above, e.g. RF = Reduction Fitting

Order No.	Designation
384555	Reduction fitting-RF-FM-M16x1,5-1/4"NPS-PN530-SSt
384559	Reduction fitting RF-FM-M16x1,5-G1/4"-PN530-SSt
384556	Reduction fitting RF-FM-M16x1,5-3/8"NPSM-PN530-SSt
34041	Reduction fitting RF-FM-1/4"NPS-M16x1,5--PN270-SSt
179732	Reduction fitting RF-FM-1/4"NPS-3/8"NPS--PN270-SSt
179247	Reduction fitting RF-FM-1/4"NPS-G1/4"--PN270-SSt




B_03221

In the large Wagner Accessories Catalogue for wet coating you will also find other material fittings.

12.5 HOSES AND ELECTRIC CABLES

12.5.1 STANDARD HOSE SETS AND COMPONENTS



Note regarding the product hose:

- Nominal pressure 25 MPa; 250 bar; 3,626 psi
- Internal diameter 4 mm; 0.16 inch
- Inner hose material PA

Pos	Stk	Order No.	Designation
1	1	2339171	GM 5000EAC hose set (7.5 m)
Consists of:			
2	1	9984573	High-pressure hose-DN4-PN270-¼"NPS-7.5 m-PA
3	1	2339152	Air hose complete (8.0 m)
4	1	2339157	GM 5000E gun cable (10.0 m)
5	7 m	3676437	Protection hose fabric PP30 (8.0 m)

Pos	Stk	Order No.	Designation
1	1	2339172	GM 5000EAC hose set (10.0 m)
Consists of:			
2	1	2302374	High-pressure hose-DN4-PN270-¼"NPS-10.0 m-PA
3	1	2339153	Air hose complete (10.5 m)
4	1	2339158	GM 5000E gun cable (15.0 m)
5	10.5 m	3676437	Protection hose fabric PP30 (10.5 m)

Pos	Stk	Order No.	Designation
1	1	2339173	GM 5000EAC hose set (15.0 m)
Consists of:			
2	1	9984573-15	High-pressure hose-DN4-PN270-¼"NPS-15.0 m-PA
3	1	2339154	Air hose complete (15.5 m)
4	1	2339159	GM 5000E gun cable (20.0 m)
5	15.5 m	3676437	Protection hose fabric PP30 (15.5 m)

Pos	Stk	Order No.	Designation
1	1	2339174	GM 5000EAC hose set (20.0 m)
Consists of:			
2	1	9984573-20	High-pressure hose-DN4-PN270-¼"NPS-20.0 m-PA
3	1	2339155	Air hose complete (20.5 m)
4	1	2339160	GM 5000E gun cable (25.0 m)
5	20.5 m	3676437	Protection hose fabric PP30 (20.5 m)


Hose colors:

Product hose yellow
Air hose blue

Dimensions:

Air hose: inside diameter 6.5 mm; 0.26 inch
Product hose: inside diameter 4 mm; 0.16 inch, nominal pressure 25 MPa; 250 bar; 3,626 psi

Material of product hose: PA



- 1 Product hose
- 2 Air hose
- 3 Electric cable


Order No.	Description	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]
2339171	GM 5000EAC hose set (7.5 m)	29±2	65±2	300±10	20±10	1500 ⁺¹⁰⁰
2339172	GM 5000EAC hose set (10 m)	29±2	65±2	300±10	20±10	1500 ⁺¹⁰⁰
2339173	GM 5000EAC hose set (15 m)	29±2	65±2	300±10	20±10	1500 ⁺¹⁰⁰
2339174	GM 5000EAC hose set (20 m)	29±2	65±2	300±10	20±10	1500 ⁺¹⁰⁰

Notes:


- (*) Melt the hose ends at both sides (gun/pump) and turn approx. 5 cm of each hose end to the inside.
 - (**) Fix the protective hose with cable ties on both sides only once at the product hose (internally)
 - (***) Fix the hose set within the protective hose approx. once per meter by means of adhesive tape, starting at distance E.
- Cable ties are only permitted at the ends of the protective hose (see **)!
(****) If the air swivel joint (Order No. 2324766) and/or the material swivel joint (Order No. 2327060) is/are used, the hose set has to be adapted accordingly.

If the air swivel joint is used, dimension A becomes 60 mm!

If the material swivel joint is used, dimension B becomes 94 mm!



12.5.2 HOSE SETS FOR LOW-RESISTANCE PRODUCTS



Note regarding the product hose:

-	Nominal pressure 25 MPa; 250 bar; 3,626 psi
-	Internal diameter 4 mm; 0.16 inch
-	Inner hose material FEP
-	Pos. 6 connecting fitting AC Order No. 2338853

Pos	Stk	Order No.	Designation
1	1	2339179	GM 5000EAC hose set (7.5 m), Low R
Consists of:			
2	1	2310468	EAC high-pressure product hose, complete (7.5 m) Low R
3	1	2339152	Air hose complete (8.0 m)
4	1	2339157	GM 5000E gun cable (10.0 m)
5	8 m	3676437	Protection hose fabric PP30 (8.0 m)

Pos	Stk	Order No.	Designation
1	1	2339180	GM 5000EAC hose set (10.0 m), Low R
Consists of:			
2	1	2310469	EAC high-pressure product hose, complete (10.0 m) Low R
3	1	2339153	Air hose complete (10.5 m)
4	1	2339158	GM 5000E gun cable (15.0 m)
5	10.5 m	3676437	Protection hose fabric PP30 (10.5 m)

Pos	Stk	Order No.	Designation
1	1	2339181	GM 5000EAC hose set (15.0 m), Low R
Consists of:			
2	1	2310470	EAC high-pressure product hose, complete (15.0 m) Low R
3	1	2339154	Air hose complete (15.5 m)
4	1	2339159	GM 5000E gun cable (20.0 m)
5	15.5 m	3676437	Protection hose fabric PP30 (15.5 m)

Pos	Stk	Order No.	Designation
1	1	2339182	GM 5000EAC hose set (20.0 m), Low R
Consists of:			
2	1	2310471	EAC high-pressure product hose, complete (20.0 m) Low R
3	1	2339155	Air hose complete (20.5 m)
4	1	2339160	GM 5000E gun cable (25.0 m)
5	20.5 m	3676437	Protection hose fabric PP30 (20.5 m)

Hose colors:


Product hose grey
Air hose blue

Dimensions:

Air hose: inside diameter 6.5 mm; 0.26 inch

Product hose: inside diameter 4 mm; 0.16 inch, nominal pressure 25 MPa; 250 bar; 3,626 psi

Material of product hose: FEP



- 1 Product hose
- 2 Electric cable
- 3 Air hose

Order No.	Description	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]
2339179	GM 5000EAC hose set (7.5 m), Low R	206±2	177±2	300±10	20±10	1500 ⁺¹⁰⁰	188±1
2339180	GM 5000EAC hose set (10 m), Low R	206±2	177±2	300±10	20±10	1500 ⁺¹⁰⁰	188±1
2339181	GM 5000EAC hose set (15 m), Low R	206±2	177±2	300±10	20±10	1500 ⁺¹⁰⁰	188±1
2339182	GM 5000EAC hose set (20 m), Low R	206±2	177±2	300±10	20±10	1500 ⁺¹⁰⁰	188±1

Notes:

- (*) Melt the hose ends at both sides (gun/pump) and turn approx. 5 cm of each hose end to the inside.
- (**) Fix the protective hose with cable ties on both sides only once at the product hose (internally)
- (***) Fix the hose set within the protective hose approx. once per meter by means of adhesive tape, starting at distance E.

Cable ties are only permitted at the ends of the protective hose (see **)!

- (****) If the air swivel joint (Order No. 2324766) is used, the hose set has to be adapted accordingly.

If the air swivel joint is used, dimension A becomes 237 mm!



12.5.3 GUN CABLES AND GUN CABLE EXTENSIONS

Order No.	Designation
2339161	GM 5000E extension cable 10m; 32.81 ft
2339162	GM 5000E extension cable 20 m; 65.6 ft




B_03219

12.6 MISCELLANEOUS

Order No.	Designation
2319653	Protective gun coating
259010	HV200 N high-voltage tester
2326041	Paint resistance meter
999080	Wet film thickness gauge
L034-191	Ford cup #4



B_03693



P_00205



B_03692




B_03225






2309368	Assembly tool valve needle
128901	Nozzle spanner ACR
2325263	Assembly tool clamping screw
2326485	GM 5000E wall mount (left/right)
232476	Swivel joint air
2327060	Fitting-SJM-GM5000EAC-1/4"NPS (swivel product)
2327061	GM 5000EAC swivel joint kit




B_03451



B_01971



B_03681




B_03699



B_03720




B_03719



B_03720

B_03719



A series of horizontal lines for writing, starting from the top right and extending down the page. The lines are evenly spaced and cover most of the page's width.

13 SPARE PARTS

13.1 HOW CAN SPARE PARTS BE ORDERED?

Always supply the following information to ensure delivery of the right spare part:

Order number, designation and quantity

The quantity need not be the same as the number given in the quantity column "Stk" on the lists. This number merely indicates how many of the respective parts are used in each component.

The following information is also required to ensure smooth processing of your order:

- Billing address
- Delivery address
- Name of the person to be contacted in the event of any queries
- Type of delivery (normal mail, express delivery, air freight, courier, etc.)

Identification in spare parts lists

Explanation of column "K" (labeling) in the following spare parts lists:

- ◆ Wearing part


Note: No liability is assumed for wearing parts.

- Not part of the standard equipment but available as a special accessory.

	 WARNING
	<p>Incorrect maintenance/repair! Risk of injury and equipment damage.</p> <p>→ Have repairs and part replacements be carried out only by specially trained staff or a WAGNER service center.</p> <p>→ Before all work on the device and in the event of work interruptions:</p> <ul style="list-style-type: none"> - Switch off the energy/compressed air supply. - Relieve the pressure from the spray gun and device. - Secure the spray gun against actuation. <p>→ Observe the operating instructions for any work.</p>



13.2 GM 5000EAC SPARE PARTS LIST




GM 5000EAC spare parts list

Pos	K	Stk	Order No.	Designation
1		1	2344473	GM 5000EAC basic version
2	◆★	1	2314283	Contacting AC
3	◆★	1	9952777	High resistance, bare
4		1	9960808	Socket contact component
5		1	-	GM 5000EAC adapter, complete Details see Chapter 13.2.1
6	◆	1	2314361	Hook
7		1	-	GM 5000EAC handle, complete Details see Chapter 13.2.2
8		2	9900308	Hexagon socket head cap screw
9		1	2312183	Lid complete
10		1	9900386	Hexagon socket head cap screw
11		1	2311970	Sealing plug
12		1	2307104	Screw plug
13		1	2312180	Air regulation complete
14	◆★	1	9971182	O-ring
15	◆★	1	9971182	O-ring
16	◆	1	2314360	Trigger
17		1	2307283	Cylindrical helical spring
18		2	2310617	Oval head screw with hexagon
19	◆	1	2314359	Product hose AC, complete
20	◆	1	L011-906	Edge filter 100 mesh (for different edge filter sizes see Chapter 12.3)
21		1	2308764	Hose fitting AC
22		1	2350454	Union nut AC, complete
24	◆★	1	2308699	Cover seal
25	◆	1	2338853	Connecting fitting AC
27		1	2349376	Spacer
	◆	1	2326336	GM 5000EAC service set


◆ = Wearing part

★ = Included in service set

13.2.1 GM 5000EAC - ADAPTER SPARE PARTS LIST



B_04368



5000EAC adapter spare parts list

Pos	K	Stk	Order No.	Designation
1		1	-	GM 5000EAC adapter, complete
2	★	1	2313314	AC air manifold ring
3	◆★	1	2307180	O-ring, sheathed
4	◆★	1	2312175	Valve housing AC, complete
5	◆★	1	2312186	Valve needle AC, complete
6		1	2314272	GM 5000EAC adapter
7		1	2312181	Cascade, complete
8	◆★	1	9974166	O-ring
9		1	2307062	Clamping screw valve rod
10	◆★	1	2311562	Rod seal
11	◆	1	2313639	Valve rod unit AC
12	◆★	1	2357106	Packfing, complete
21		1	2307059	Withdrawal nut
22		1	9901411	Threaded pin with hexagon socket
24		1	2325263	Assembly tool clamping screw
		1	2326336	GM 5000EAC service set

◆ = Wearing part

★ = Included in service set

GM 5000EAC handle spare parts list


Pos	K	Stk	Order No.	Designation
1		1	-	GM 5000EAC handle, complete
2		1	2307288	Fitting
3	◆★	1	9971025	O-ring
4		1	2307290	Hose holder
5		1	2312182	Plug, complete
6		1	2314270	Handle, complete
7	★	1	2307232	Adapter seal
8		1	2311952	Stop screw
9		1	2309825	Oval head screw with hexagon
10	◆★	1	2310692	Seal
11		1	2311182	Straight pin
12		1	2309400	Safety clip
13		1	2312189	Air valve
18	◆★	1	9974218	O-ring
23	◆★	1	9974166	O-ring
		1	2326336	GM 5000EAC service set

◆ = Wearing part

★ = Included in service set

13.3 ACCESSORIES SPARE PARTS LISTS

13.3.1 FLAT JET NOZZLES SPARE PARTS LIST




Flat jet nozzles spare parts list

Pos	K	Stk	Order No.	Designation
1		1	2350454	Union nut AC, complete
2		1	2309882	ACF 5000 air cap - LV (red)
		1	2314203	ACF 5000 air cap - HV (blue)
3	◆	1	2311777	Nozzle guard AC
4	◆	1	2344488	Union nut AC
5	◆	1	2311217	O-ring, sheathed
6	◆	1	2319525	Flat electrode set

◆ = Wearing part

13.3.2 ACR 5000 ROUND JET NOZZLE CAP SPARE PARTS LIST



ACR 5000 round jet nozzle cap spare parts list

Pos	K	Stk	Order No.	Designation
1		1	2344483	ACR 5000 round jet nozzle cap
2		1	2307220	Nozzle nut
3	◆	1	2315310	O-ring
4	◆	1	132351	Nozzle screwed connection holder
5		1	2344487	Nozzle body
6	◆	1	2319526	Round electrode set
9	◆	1	132516	Nozzle screw joint, complete
10	◆	1	2307216	Sealing fitting
11	◆	1	2311217	O-ring
12		1	128901	Nozzle wrench, complete

◆ = Wearing part

14 WARRANTY

14.1 IMPORTANT NOTES REGARDING PRODUCT LIABILITY

As a result of an EC regulation effective from January 1, 1990, the manufacturer shall only be liable for his product if all parts originate from him or are approved by him, and if the devices are properly mounted, operated and maintained.

The manufacturer will not be held liable or will only be held partially liable if third-party accessories or spare parts have been used.

With genuine WAGNER accessories and spare parts, you have the guarantee that all safety regulations are complied with.

14.2 WARRANTY CLAIM

Full warranty is provided for this device:

We will at our discretion repair or replace free of charge all parts which within 24 months in single-shift, 12 months in 2-shift or 6 months in 3-shift operation from date of receipt by the purchaser are found to be wholly or substantially unusable due to causes prior to the sale, in particular faulty design, defective materials or poor workmanship.

The type of warranty provided is such that the device or individual components of the device are either replaced or repaired as we see fit. The resulting costs, in particular shipping charges, road tolls, labour and material costs will be borne by us except where these costs are increased due to the subsequent shipment of the device to a location other than the address of the purchaser.

We do not provide warranty for damage that has been caused or contributed to for the following reasons:

Unsuitable or improper use, faulty assembly or commissioning by the purchaser or a third party, normal wear, negligent handling, defective maintenance, unsuitable coating products, substitute products and the influence of chemical, electrochemical or electrical agents, except when the damage is attributable to us.

Abrasive coating products such as red lead, emulsions, glazes, liquid abrasives, zinc dust paints and so forth reduce the service life of valves, packings, spray guns, nozzles, cylinders, pistons etc. Wear and tear due to such causes are not covered by this warranty.

Components that have not been manufactured by WAGNER are subject to the original warranty of the manufacturer.

Replacement of a component does not extend the period of warranty of the device.

The device should be inspected immediately upon receipt. To avoid losing the warranty, we or the supplier company are to be informed in writing about obvious faults within 14 days upon receipt of the device.

We reserve the right to have the warranty compliance met by a contracting company.

The services provided by this warranty are dependent on evidence being provided in the form of an invoice or delivery note. If the examination discovers that no warranty claim exists, the costs of repairs are charged to the purchaser.

It is clearly stipulated that this warranty claim does not represent any constraint on statutory regulations or regulations agreed to contractually in our general terms and conditions.

WAGNER



Order No. 2344500
Edition 07/2014

Germany

J. WAGNER GmbH
Otto-Lilienthal-Str. 18
Postfach 1120

D- 88677 Markdorf

Phone +49/ (0)7544 / 5050
Fax +49/ (0)7544 / 505200
E-mail service.standard@wagner-group.com

Switzerland

J. WAGNER AG
Industriestrasse 22
Postfach 663

CH- 9450 Altstätten

Phone +41/ (0)71 / 757 2211
Fax +41/ (0)71 / 757 2222

More contact addresses on the Internet at:

www.wagner-group.com

Enterprises/Sites/WAGNER worldwide

Subject to changes without notice